



KEY	PART #	DESCRIPTION	KEY	PART #	DESCRIPTION	KEY	PART #	DESCRIPTION
	<b>9508</b>	<b>Air Driven Blower</b>	11	9505-06	Feet	22	9850-AA	Compressor
1	9500-77	Machine Screw	12	9500-63	Flat Washer	23	9000-01	Closed Nipple (STD)
2	9800-62	Flat Washer	13	9500-75	Machine Screw	24	9850-09	Muffler Assembly
3	9500-74	Bolt	14	9500-68	K-Nut	25	9000-16	Elbow
4	9500-70	Lock Washer	15	9534-02	Fan Guard	26	9850-95LW	Lubricator
5	9504-03B	Gasket, Cent. Housing	16	9800-66	Machine Screw	27	9875-08	Gauge
6	9512-03	Base	17	9500-69	Lock Nut	28	9895-95RW	Regulator
7	9504-03RM	Blower Housing	18	9501-03	Fan Wheel (Aluminum)	29	9850-20	Ball Cock Valve
8	9872-07	Joiner Set	19	9500-91	Socket Set Screw	30	9000-23	Pipe Nipple
9	9504-03A	Mounting Plate	20	9505-05	Motor Bracket	31	9872-31	Micron Filter
10	9800-64	Lock Nut, Nylon	21	9505-09A	Shaft Key			