



A1500EX (9833)

KEY	PART #	DESCRIPTION	KEY	PART #	DESCRIPTION	KEY	PART #	DESCRIPTION
	9832	A1500 TE	14	9700-77	Inlet Filter Assembly	30	9700-04	Pressure Gauge
	9833	A1500 EX	15	9832-03	Fan Guard	31	9000-11	Chrome Hex Bushing (Optional)
1	9832-99	Motor, 1 1/2 hp	16	9800-69	Machine Screw	31	9000-12	Chrome Hex Bushing (STD)
2a	9865-14	Switch Guard	17	9800-68	Machine Screw	32	9000-13	Galvanized Cross
2b	9865-13	Toggle Switch	18	9800-67	Machine Screw	33	9000-1	Chrome Hex Bushing
3	9800-77	Yellow Ring	19	9800-64	Nylon Lock Nut	34	9833-100	Motor, 1 1/2 hp (EX Single Phase)
4	9800-78	Yellow Spade	20	9700-06	Rubber Feet	35	9503-03	Receptacle 20 Amp -125 Volt (EX) (Sold Separately)
5	9831-75	Electric Cord	21	9831-88	Pump Base Plate	36	9503-02	Plug 20 Amp -125 Volt (EX)
6	9800-79	Set Screw	22	9800-74	Tap Bolt	37		Coupler (See Coupler Page)
7	9832-50	Coupling Half	23	9800-82	Shroud	38	9832-02	Fan
8	9800-80	Set Key	24	9700-76	Pressure Relief Valve			Accessories (Not Shown)
9	9832-51	Spacer	25	9000-10	Nipple	9700-55		Service Kit (Includes Vanes (Set of 4), Filters, and Flushing Liquid)
10	9800-81	Cooling Fan	26	9000-14	Galvanized Tee	9700-65		Universal Inlet Hose Kit (50 ft.)
11	9800-73	Tap Bolt	27	9700-78	Exhaust Filter Assembly (w/Filter)	9700-57S		Vanes (set of 4)
12	9832-AA	Pump (Includes #15, 38, 6-10)	28	9700-02	Exhaust Filter Element			
13	9700-01	Inlet Filter Element	29	9700-15C	Exhaust Filter Canister			